

**HYDRAULIC WINCHES
20BCX4L2G
AND
20BCX4R2G**

TABLE OF CONTENTS

WARNING AND CAUTION NOTICES - READ BEFORE OPERATING PRODUCT
OPERATING PROCEDURES FOR SHIFTING GEARS
DIMENSIONAL – 20BCX4L2G & 20BCX4R2G WINCHES
WIRE ROPE INSTALLATION
HYDRAULIC SYSTEM
PLUMBING DIAGRAM
GENERAL INFORMATION AND DP SERVICING INSTRUCTIONS

INSTALLATION DRAWING - MOTOR END - EXPLODED VIEW
PARTS LIST - MOTOR END.....1.10111

INSTALLATION DRAWING - DRUM - EXPLODED VIEW
PARTS LIST - DRUM.....1.20084

INSTALLATION DRAWING - GEAR END - EXPLODED VIEW
PARTS LIST - GEAR END.....1.30121


INSTALLATION DRAWING - INPUT SHAFT - EXPLODED VIEW
PARTS LIST - INPUT SHAFT.....1.40231

INSTALLATION DRAWING - BASE MOUNT - EXPLODED VIEW
PARTS LIST - BASE MOUNT.....1.50267

INSTALLATION DRAWING - GEAR END COVER - EXPLODED VIEW
PARTS LIST - GEAR END COVER.....1.60108


BOLT TORQUE CHART

WARRANTY, OIL SPECIFICATIONS AND HOW TO ORDER PARTS



DANGER

**DO NOT DISENGAGE
WINCH UNDER LOAD**



DANGER

**THE LAST FIVE
WRAPS OF WIRE ROPE
MUST BE LEFT ON
THE DRUM TO ASSIST
THE WIRE ROPE CLAMP IN
HOLDING THE LOAD**



WARNING

**WINCHES ARE NOT
TO BE USED FOR
THE LIFTING OR
MOVING OF
PERSONS**

OPERATING PROCEDURE FOR SHIFTING GEARS

The following steps are necessary for proper gear shifting operations.

Single Speed Gearbox*

Gear Dis-Engagement:

1. Winch must be "at rest" and have **no** load on cable.
2. Shift winch to out of gear "*free spool*" mode.

Gear Engagement:

1. Winch must be "at rest" and have **no** load on cable.
2. Shift winch to in-gear mode and **slowly** rotate drum 90° in pay out direction, and then **stop** rotation. Next, **slowly** rotate drum in pay in direction to insure gears are fully engaged and **begin** paying in of load.

Two Speed Gear Box*

Low Gear to High Gear:

1. Winch must be "at rest" and have **no** load on cable.
2. Shift winch from low gear to high gear and **slowly** rotate drum 90° in pay out direction, and then **stop** rotation. Next, **slowly** rotate drum in pay in direction to insure gears are fully engaged and **begin** paying in of load.



High Gear to Low Gear:

1. Winch must be "at rest" and have **no** load on cable.
2. Shift winch from high gear to low gear and **slowly** rotate drum 90° in pay out direction, and then **stop** rotation. Next, **slowly** rotate drum in pay in direction to insure gears are fully engaged and **begin** paying in of load.

* Also applies for two speed gear box with neutral position

WARNING!

If your winch has ever been "*shifted under load*" or has ever encountered "*rotational face contact of non-engaged gear components*," the gear teeth could be damaged. Damaged gear teeth can prevent your winch from fully engaging into gear and could allow it to jump out of gear. If this has happened to your winch, this procedure may *not* insure that it is fully engaged and it may need to be inspected for possible gear damage.



RECOMMENDED BREAK-IN PROCEDURE

FULLY EXTEND CABLE AND MAKE (3) COMPLETE PULLS AT APPROXIMATELY HALF THE RATED CAPACITIES. THIS WILL EXTEND THE LIFE OF BOTH THE CABLE AND THE WINCH.

| WINCH PERFORMANCE | | | |
|-------------------|-------------------|-----------|------------|
| LAYER | 9/16 Ø CABLE CAP. | LINE PULL | LINE SPEED |
| 1 | 31 | 20000 | 27 |
| 2 | 68 | 16600 | 32 |
| 3 | 111 | 14200 | 37 |
| 4 | 160 | 12500 | 43 |
| 5 | 216 | 11100 | 48 |
| 6 | 278 | 9950 | 54 |

THE RATED LINE PULLS SHOWN ARE FOR THE WINCH ONLY. CONSULT THE WIRE ROPE MANUFACTURER FOR WIRE ROPE RATINGS. LINE SPEED IS BASED ON 20 GPM FLOW RATE (MAX FLOW OF 20 GPM). LINE PULL IS BASED ON 2200 PSI. OPTIONAL LOWER PRESSURE MOTORS ARE ALSO AVAILABLE. CABLE CAPACITIES ARE IN ACCORDANCE WITH SAE J706, WITH THE EXCEPTION OF THE LAST WRAP. (ACTUAL CAPACITIES ARE USUALLY UP TO 10% GREATER THAN THOSE SHOWN).

COMMERCIAL INTERTECH MOTOR



TO REVERSE WIRE ROPE PULL IN DIRECTION

METHOD 1

REMOVE THE COUNTERBALANCE VALVE AND OUTLET FLANGE.
REMOVE THE MOTOR MOUNTING BOLTS AND ROTATE THE MOTOR 180°.
REASSEMBLE MOTOR, COUNTERBALANCE VALVE, AND OUTLET FLANGE.

METHOD 2

SWITCH POSITIONS OF COUNTERBALANCE VALVE AND OUTLET FLANGE.
NOTE: HOSES GOING TO BRAKE HOUSING MAY NEED TO BE LONGER.




CHAR-LYNN MOTORS

(STD) L PRESSURE TO V1 ROTATES WINCH DRUM
CLOCKWISE WHEN VIEWED FROM MOTOR END.

R PRESSURE TO V2 ROTATES WINCH DRUM COUNTER
CLOCKWISE WHEN VIEWED FROM MOTOR END.


TO REVERSE WIRE ROPE PULL DIRECTION,
SWITCH POSITIONS OF CARTRIDGE AND PLUG.




(STD) L PRESSURE TO V1 ROTATES WINCH DRUM COUNTER
CLOCKWISE WHEN VIEWED FROM MOTOR END.

R PRESSURE TO V2 ROTATES WINCH DRUM
CLOCKWISE WHEN VIEWED FROM MOTOR END.

TO REVERSE WIRE ROPE PULL DIRECTION,
SWITCH POSITIONS OF CARTRIDGE AND PLUG.




TYPICAL WINCH HYDRAULIC SYSTEM



ALL UTILITY UNITS ARE BI-DIRECTIONAL WITHOUT MANIPULATION OF CARTRIDGE, AND OR PLUG LOCATIONS.

NOTE: IF TENSIONER AND, OR FAIRLEAD OPTIONS EXIST, THEN REVERSAL OF THEIR POSITION
IN RELATION TO WINCH MUST TAKE PLACE BEFORE REVERSAL OF WIRE ROPE PULL DIRECTION CAN OCCUR.

WINCH PLUMBING DIAGRAM



REFER TO 1.10111 MOTOR END PARTS LIST

SERVICE INSTRUCTIONS DP BRAKE

GENERAL:

The winch is fully hydraulic with a multi disc wet brake. The brake is spring applied and hydraulically released, and will automatically set any time the winch control valve is in neutral or in case of power failure. When the hydraulic pressure is less than 270 psi, the brake will set. Hydraulic power must be restored before brake will release. Maximum brake torque is achieved at 0 psi. (These winches are not to be used for moving or lifting people.)

DISASSEMBLY OF BRAKE

(REFER TO MOTOR END INSTALLATION DRAWING 1.10111)


1. Disconnect brake hoses (item 23) at connections (item 24) on brake housing (item 3). wrap hose ends to prevent dirt contamination.
2. Disconnect motor (item 1) from brake housing (item 3) by removing two capscrews (item 19), lock washers (item 20). Allow oil to drain.
3. Remove outer brake housing (item 3) by removing six capscrews (item 21) and lock washers (item 22).
CAUTION: Since housing is under spring loading of approximately 3,500 lbs., the capscrews should be loosened evenly until spring force has been relieved.
4. In removing housing (item 3), the bearing (item 16) may come with it or remain on brake shaft (item 5), or the brake shaft may also slide out.
5. Remove o-ring (item 10) from end support (item 4).
6. Remove friction plates (item 7), drive plates (item 8), spacer ring (item 26), and dowel pins (item 9), from piston (item 6).
7. Remove piston (item 6) from end support (item 4) being careful not to damage o-rings on piston or end support. Next, remove o-rings and back-up rings (item 11, 12, 13, & 14) from piston.
8. Finally, remove springs (item 17) and bearing (item 16) from end support (item 4).

ASSEMBLY OF BRAKE

1. Lubricate all o-rings and back-up rings with clean hydraulic oil used in the system.
2. Clean all parts thoroughly and visually examine for cuts, dents or other damage before assembly. Repair or replace parts with such defects.
3. Install bearing (item 16) into end support (item 4). Then insert twelve springs (item 17) into holes in end support. Next, insert shaft (item 5) into bearing (item 16).
4. Insert dowel pins (item 9) into respective holes in end support (item 4).
5. Assemble o-rings and back up rings (item 11, 12, 13, & 14) on piston (item 6). Position back up rings as illustrated.
6. Insert piston (item 6) fitted with seals into end support (item 4) and over dowel pins (item 9) and tap down until piston face is resting against springs (item 17).
7. Insert spacer ring (item 26), then insert a friction plate (item 7) alternating with a drive plate (item 8) into piston (item 6) and over shaft (item 5) until all plates are in place in sequence illustrated.
8. Next, place bearing (item 16) onto brake shaft (item 5).
9. Place o-ring (item 10) in position on end support (item 4). Finally and with care not to pinch o-ring seals on piston, slide the housing (item 3) into place over the dowel pins (item 9) and tap down until firm. Install lock washers (item 22) and capscrews (item 21) in place until all six shoulder up. proceed to tighten evenly against spring pressure until housing face (item 3) is in full contact and capscrews are torqued to 50 ft. lbs.
10. The motor (item 1) and o-ring (item 30) can now be reinstalled on the housing (item 3). Then insert into brake housing (item 3) and secure with capscrews (item 19), lock washers (item 20). Reconnect brake hoses (item 23) as shown on winch plumbing diagram.
11. Refill winch with oil through gear end cover fill port (refer to gear end cover installation drawing). Allow time for oil to travel through brake end.
12. Before running winch, loosen adapter connections (item 24) at brake slightly to bleed air from brake release hoses (item 23) with hydraulic oil under pressure. Retighten connections and winch is ready to operate.
(Note: pressure should not exceed 100 psi during bleeding.)

BRAKE TROUBLE SHOOTING

1. Brake will not release:
 - (a) Insufficient system pressure to brake.
 - (b) Damaged o-rings or back up ring seals (item 11, 12, 13, or 14).
 - (c) Damaged piston (item 6).
 - (d) Damaged seal surfaces within housing (item 3).
 - (e) Damaged bearing (item 16).
 - (f) Friction or drive plates (items 7 or 8) warped or heat damaged.
2. Brake will not apply or applies but torque low:
 - (a) Damaged springs (item 17), either broken or heat damaged and having taken a permanent set.
 - (b) Friction plates (item 7) worn out.
3. Oil leaks externally from brake:
 - (a) Damaged o-ring seal (item 10).



MOTOR END INSTALLATION
1.101111


1.10111 PARTS LIST
MOTOR END INSTALLATION

| <u>LOC.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QTY</u> |
|-------------|-----------------|---|------------|
| 1 | 73067 | MOTOR-HYDRAULIC | 1 |
| 2 | 11604 | VALVE - COUNTERBALANCE | 1 |
| 1. | 9817 | O-RING - 13/16 I.D. x 3/32 SECTION | 2 |
| 3 | 11535 | HOUSING - BRAKE - OUTER | 1 |
| 4 | 11995 | SUPPORT - MOTOR END | 1 |
| 5 | 11750 | SHAFT - BRAKE | 1 |
| 6 | 11443 | PISTON-BRAKE | 1 |
| 7 | 11603** | PLATE - DISC - FRICTION | 5 |
| 8 | 3159** | PLATE - DRIVE - BRAKE | 4 |
| 9 | 3263 | PIN - DOWEL - 5/16 x 3 1/2 | 2 |
| 10 | 9844# | O-RING - 6 3/4 I.D. x 7 O.D. x 1/8 SECTION | 1 |
| 11 | 9853# | O-RING - 6 1/2 I.D. x 3/16 SECTION | 1 |
| 12 | 9851# | O-RING - 5 3/8 I.D. x 3/16 SECTION | 2 |
| 13 | 9854# | RING - BACKUP - 6 1/4 I.D. x .183 | 1 |
| 14 | 9852# | RING - BACKUP - 5.278 I.D. x .076 | 1 |
| 16 | 81434 | BEARING - BALL - 1 3/4 I.D. | 2 |
| 17 | 2319** | SPRING - COMPRESSION - 3/4 | 12 |
| 18 | 1345 | CAP SCREW - SOCKET HEAD - 3/8 - 16UNC x 2 1/2 | 3 |
| 19 | 1143 | CAP SCREW - SOCKET HEAD - 1/2 - 13NC x 1 1/2 | 2 |
| 20 | 1144 | WASHER - LOCK - HI COLLAR - 1/2 | 2 |
| 21 | 1376 | CAP SCREW - HEX HEAD - 7/16-UNC x 2 1/2 - GRADE 8 | 6 |
| 22 | 1388 | WASHER - LOCK - 7/16 | 6 |
| 23 | 75038 | HOSE - 1/4 - R1 x 12" | 2 |
| 24 | 76017 | ADAPTER - 90° - SWIVEL | 2 |
| 25 | 10708* | TAG - WARNING | 1 |
| 26 | 11486 | SPACER | 1 |
| 27 | 76029 | ADAPTER - 45° | 1 |
| 28 | 3177 | CARTRIDGE - COUNTERBALANCE | 1 |
| 29 | 70035 | PLUG ASSEMBLY - VALVE - C'BAL | 1 |
| 30 | 9880 | O-RING - 3 I.D. x 1/8 SECTION | 1 |
| 31 | 76027 | ADAPTER | 1 |

* NOT SHOWN IN EXPLODED DRAWING.

** THESE ITEMS SOLD IN 9401 KIT ONLY.


THESE ITEMS SOLD IN 9406 KIT ONLY.



DRUM INSTALLATION
1.20084

1.20084 PARTS LIST
CABLE DRUM INSTALLATION


| <u>LOC.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QTY.</u> |
|--------------------|----------------------------|--|--------------------|
| 1 | 12350 | DRUM | 1 |
| 2 | 11947 | BEARING – BRONZE – 3 ½ I.D. x 3 ¾ O.D. | 2 |
| 3 | 9929 | SEAL – SHAFT – 3 5/8 I.D. x .357 | 2 |
| 4 | 10529 | WEDGE – CABLE – 7/16 | 1 |



GEAR END INSTALLATION
1.30121

1.30121 PARTS LIST
GEAR END INSTALLATION

| <u>LOC.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QTY.</u> |
|-------------|-----------------|------------------------------------|-------------|
| 1 | 13374 | SUPPORT - GEAR END | 1 |
| 2 | 81107 | GEAR - RING | 1 |
| 3 | 13379 | ASSEMBLY - CARRIER - SECONDARY | 1 |
| 4 | 13380 | GEAR - SUN - SECONDARY | 1 |
| 5 | 12572 | WASHER - THRUST - NYLON | 1 |
| 6 | 12083 | WASHER - THRUST - NYLON - PRIMARY | 1 |
| 7 | 9897 | O-RING - 6 1/2 I.D. x 3/32 SECTION | 1 |
| 8 | 3412 | CARRIER - PRIMARY | 1 |
| 9 | 13385 | WASHER - THRUST | 1 |
| | | | 2 |




INPUT SHAFT INSTALLATION
1.40231

1.40231 PARTS LIST
INPUT SHAFT INSTALLATION

| <u>LOC.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QTY.</u> |
|--------------------|----------------------------|---------------------------|--------------------|
| 1 | 13384 | INPUT SHAFT | 1 |





BASE MOUNT INSTALLATION
1.50267

1.50267 PARTS LIST
BASE ANGLE INSTALLATION

| <u>LOC.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QTY.</u> |
|--------------------|------------------------|---|--------------------|
| 1 | 11570 | BASE ANGLE | |
| 2 | 13587 | SPACER - PLATE | 2 |
| 3 | 1404 | CAP SCREW - HEX HEAD - 1/2 - 13NC x 1 3/4 - GRADE 8 | 2 |
| 4 | 1403 | CAP SCREW - HEX HEAD - 1/2 - 13NC x 1 1/2 - GRADE 5 | 8 |
| 5 | 1490 | NUT - HEX - 1/2 - 13NC - GRADE 2 | 8 |
| 6 | 1495 | WASHER - LOCK - 1/2 | 16 |
| 7 | 10466* | PLATE - ID - WINCH | 16 |
| 8 | 1165* | RIVET - TYPE - U | 1 |
| | | | 4 |


* NOT SHOWN ON EXPLODED DRAWING.

1.60108 PARTS LIST
GEAR END COVER INSTALLATION

| <u>LOC.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QTY.</u> |
|-------------|-----------------|---|-------------|
| 1 | 13370 | COVER - GEAR END | 1 |
| 2 | 13372 | COUPLING - DRIVE | 1 |
| 3 | 13373 | PISTON - AKO | 1 |
| 4 | 13386 | GEAR - SUN | 1 |
| 5 | 13296 | CYLINDER - PISTON | 1 |
| 6 | 3632 | RING - RETAINER - ROUND - 3 O.D. x 3.4 GAGE | 1 |
| 7 | 2309 | SPRING - COMPRESSION | 1 |
| 8 | 81612 | BUSHING - BRONZE - 5/8 O.D. x 3/8" I.D. x 3/8 | 1 |
| 9 | 3303 | RING - RETAINER - 1 1/4 x .05 THICK | 1 |
| 10 | 3321 | RING - RETAINER - 7/8 x .08 - THICK - ROUND SECTION | 1 |
| 11 | 9672 | O-RING - 2 5/8 I.D. x 1/8 SECTION | 1 |
| 12 | 9704 | O-RING - 2 1/8 I.D. x 2 3/8 O.D. SECTION | 2 |
| 13 | 76343 | PLUG - SOCKET HEAD - O-RING - BOSS - MAGNETIC #10 | 1 |
| 14 | 76344 | PLUG - O-RING - BOSS - #10 - SOCKET HEAD - 7/8 - 14 | 1 |
| 15 | 3004 | CAP SCREW - HEX HEAD - 5/16" - 18 x 4 3/4 - GRADE 8 | 1 |
| 16 | 1168 | WASHER - LOCK - 5/16 | 8 |
| 17 | 9897 | O-RING - 6 1/2 I.D. x 3/32 SECTION | 8 |
| 18 | 1157* | CAPLUG - #4 RED - 1/4 NPT | 1 |
| | | | 1 |

* NOT SHOWN ON EXPLODED DRAWING.





AIR KICKOUT
 GEAR END COVER INSTALLATION
 1.60108